


In order to protect the environment, when the product or its components are scrapped, please dispose of it as industrial waste; or hand it over to the recycling station for disaggregation, recycling and reuse according to relevant national regulations

CHINT


A



	L3	L4	L5	L6	L8	L10	H1	H3	H4	H5	W1	W2	d1
3P	275	445	485	10	141	40	270	61	42.5	62.5	65	281	13
4P	275	445	485	10	141	40	270	61	42.5	62.5	65	346	13

B

mm




	A	B	d2
3P	130	141	7
4P	195	141	7

C

mm

Rear plate installation

Front plate installation



Rear/Front plate installation						
	L8	W5	L9	L7	W4	d3
3P	141	130	177	95/200	200	7
4P	141	195	177	95/200	265	7

Zhejiang CHINT Electric Co., Ltd.
 Add: No.1, CHINT Road, CHINT Industrial Zone, North Baixiang,
 Yueqing, Zhejiang Province.
 Tel: 86-577-62777777 4001177797
 Fax: global-sales@chint.com
 Web: <http://en.chint.com>



